

Coding HT3 Remote to Motor

Remove the face plate of the motor to locate the radio set button.

The radio set button is generally yellow but the colour may vary depending on your motor model.

Press the radio set button on your motor once and release.

A light will illuminate on your motor.

Press and hold the button on the new remote which you wish to operate the motor until the light on the motor goes out.

Your remote is now programmed. Please push the button on the remote to test.

www.remotepro.com.au